



SPORT-ON



SPORT-ON



+48 604 55 88 16



TOKARSKA 13,
BUKOWIEC 58-540, POLAND



INFO@SPORT-ON.COM



WWW.SPORT-ON.COM

EXPLORER³

SPECS:**Frame material:** Aluminum alloy**Front/Rear suspension:** Double a-arms F and wishbone R**Shocks:** Rock Shox Monarch XX/RL**Steering system:** Handlebar and chest steering system**Cranks:** Schlumpf Mountain-Drive 27T sprocket**Pedals:** Custom designed, ergonomically shaped**Intermediate set of gears:** Bearing hub with 22T/28T**Rear hub:** Shimano Alfine 8**Seat/Footrests:** Adjustable carbon-fibre seat and footrests**Chest steering:** Adjustable (up,down,angle)**Handlebar:** Amoeba Borla**Stem:** Customized Amoeba Borla**Brakes:** Hydraulic Shimano XT**Brake discs:** 180mm (7")**Shifter:** Alfine**Headsets:** Custom designed**Spokes:** Sapim**Front hubs:** Novatec NT-DH41 SB / 20mm axles**Tires:** Continental or Schwalbe 26x2,3"**Tubes:** 26"**Rims:** Dartmoor Rocket/Rider/Shield depending on version.**Dimensions with wheels:** L=214cm W=98cm H=70cm**Weight:** 23 kg (without the electric assist)**OPTIONS:**

Shimano Alfine 11G hub

10 spd derailleur Shimano XT, cassette XT 11-36T

Custom Colour

Front lights MacTronic Scream Combo

Front lights MacTronic Noise Combo

Bottle cage, Electric assist, Bike Computer

Jersey, Cap, T-shirt



The Explorer III Off-Road Handcycle is a unique handcycle designed to tackle extreme off-road conditions and provide unparalleled opportunities to get up close and personal with places that until now have been inaccessible. Places like mountains, trails and the beach are no longer out of bounds, the Explorer Off-Road Handcycle will take you there and to the top. This unique off-road handcycle has already taken many users to the highest peaks of Europe, including the Alps and the Tatra mountains. The Explorer also took part in a successful climbing expedition to Mount Killimanjaro - the highest peak of Africa. The Explorer III is the most advanced off-road handcycle of its kind with features such as full independent suspension, hydraulic disc brakes all round, Schlumpf Mountain Drive and a choice of drivetrain ranging from 16-22 gears. One of the great features of the Explorer is the chest steering used to keep the bike in a straight line or negotiate turns when pedaling. The handlebars are there for flying downhill.